

# Architectural Designer Frame OPTDF2



This product is used for the visual enhancement of the TEC/CAT 2 and 4 And the older HF series door access unit.

OPTDF2 is shown installed on a CAT4 door access unit

To install this product:

- 1) Make sure the 4 set screws ( 2 top and 2 bottom) are loose enough so as not to interfere with putting the frame into position
- 2) Place frame over door and press firmly into place so the frame is tight against the door face.
- 3) Tighten the 4 set screws securely with the Allen wrench provided.

Note: This product is designed for easy removal if installed on a unit that is flush mounted. To service the unit remove the frame by loosening the 4 set screws. Reinstall frame when service is complete by following the steps above.