

This Technical Support Note (TSN) provides instructions for installing Selcom Premium Demo software.

### Software Version to be Installed

Selcom Premium Demo v7.1.2

### Compatible Windows® Operating System Versions

Windows® 10, 8.1, 8, 7 and Vista.

### User Requirements for Software Installation

Users must:

- Have full administrative privileges
- Ensure that the User Account Control is set to maximum
- Be able to properly uninstall Applications using the Windows® Control Panel

**If in doubt, please contact your system administrator.**

## INSTRUCTIONS

NO USER DATA FILES WILL BE LOST DURING THIS PROCESS.

**Uninstall** any previous versions of Selcom Premium Demo already installed.

**To Install the Selcom Premium Demo v7.1.2 Software, use one of the following options:**

### From the Website

Download the installation file from the following web page link: <http://www.selectses.com/software-download/> then double-click the Selcom Premium Demo v712.msi file to install the software.

### Using a Selcom Premium Demo CD or USB Flash Drive

Insert the CD into your CD player (if available) or USB flash drive into an available USB slot. After insertion, if Windows® asks what you wish to do, click "Run Selcom Premium Demo v712.msi". Otherwise, select "Open Folder to View Files".

### To Run the Software

***During installation, a shortcut "Selcom Premium Demo 7\_1\_2.exe" will be placed on your desktop.***

Run the software by double-clicking this shortcut.

**When asked to login**, please use the following –

Login name: ses

Password: ses